

VF5 AC voltage detector with flashlight

Quick start guide

EN - FR - ES - ESLT - DE

SAFETY WARNINGS

- Read, understand and follow Safety Warnings and Operating Instructions in the manual before using this product.
- The detector's safety features may not protect the user if not used in accordance with the manufacturer's instructions.
- Check on a known live source within the rated AC voltage range of the detector before use to ensure it is in working order.
- Insulation type and thickness, distance from the voltage source, shielded wires, and other factors may affect reliable operation.
- The VF5 may help in the indication of live AC circuits only and must not be used as verification of a de-energised circuit. This is not a Safety Test Lamp.
- Do not use if the detector appears damaged or if it is not operating properly. If in doubt, replace the product.
- Do not use on voltages that are higher than as marked on the VF5.
- Use caution with voltages above 30 V AC as a shock hazard may exist.
- Comply with all applicable safety codes. Use approved personal protective equipment when working near live electrical circuits-particularly with regard to arc-flash potential.
- Do not operate detector if Low Battery warning occurs. Replace batteries immediately.

NOTE: The VF5 is unable to detect voltage on armoured or sheathed cable, or on cable in conduit, behind panels or in metallic enclosures.

CATIV Measurement category IV: Equipment connected between the origin of the low-voltage mains supply outside the building and the consumer unit.

CATIII Measurement category III: Equipment connected between the consumer unit and the electrical outlets.

CATII Measurement category II: Equipment connected between the electrical outlets and the user's equipment.

⚠️ INTERNATIONAL SAFETY SYMBOLS :





- ⚠️ Potential danger. Indicates the user must refer to the manual for important safety information
- ⚠️ Indicates hazardous voltages may be present
- Equipment is protected by double or reinforced insulation
- CE Equipment complies with current EU directives
- ♻️ End of life disposal

Detector Description



- | | |
|---------------------------|-------------------|
| 1. Screw on battery cover | 5. On/Off button |
| 2. Torch | 6. LED indicators |
| 3. Torch button | 7. Detector tip |
| 4. 12 V button | 8. Work light |

Operation

1. **Turning the VF5 on:** Momentarily press the detector  On/Off button. The sounder will beep once, vibrate once and the green LED will illuminate to indicate that the detector is on and ready for use.
2. **Turning the VF5 off:** Momentarily press the  On/Off button. The VF5 will beep twice, vibrate twice and the green LED will turn off.
3. **Turning the Sounder off and Vibrating motor off:** Turn the VF5 on as described above. The VF5 will now operate with both the sounder and the vibrating motor. To turn the sounder and vibrating motor off, press and hold the  On/Off button until the green LED flashes once. To turn the sounder and vibrating motor back on press and hold the  On/Off button until the green LED flashes, the sounder beeps and the unit vibrates.
4. **Verify Operation:** Before using VF5, (1) Make sure the green LED is glowing, (2) Check VF5 on a known live AC voltage that is within the defined detection range of the VF5.
5. **Low Voltage Mode (12 V to 1000 V AC):** Turn on the VF5. Press and hold the 12 V button. The green LED will change to orange to indicate the VF5 is in the low voltage mode. While pressing the 12 V button place the tip of the VF5 near an AC voltage. When AC voltage is detected the LED will turn red and flash, the sounder will beep and the detector will vibrate. The flash, beeping and vibration rate will increase as the VF5 gets closer to the voltage source. If the VF5 detects a medium voltage (100 V – 1000 V) it will automatically change over to the medium voltage mode, the red LED will change to a steady glow, the sounder will beep rapidly and the detector will vibrate constantly.